

IR-Remote Controller Director Premium

We have developed an universal remote controller for our premium audio components. The Director Premium enables the remote control of three types of Trigon Audio Components:



Pre- and Integrated Amplifier



CD-Player



Streamer and Mediaplayer




The Director Premium uses infrared (IR) codes, which are activated when pushing the buttons on the remote control.

The technology used in this remote control is designed to be completely upgradeable through software reprogramming (at the factory), at any time to support all future Trigon audio component releases. This upgrade path insures that your investment in the Director Premium will be secured. With that, we thank you for your purchase and wish you all the best.

The Director uses self-explanatory graphical symbols on the control interface that can be used over a wide range of product types. The use of symbols allows one button to control a variety of functions in different components. The explanations of these functions are explained in clear text below for each component type. The result is a clearly laid out control interface that, with a little time, will be completely comfortable in every day use.

Use the following table to determine what key functions for the corresponding devices are explained.

	 Pre- and Integrated Amplifier	 CD-Player	 Streamer, Mediaplayer
	Power ON/OFF	Power ON/OFF, (1)	Power ON/OFF (1),(2)
	Display ON/OFF	Display ON/OFF, (2)	No Function (1) Display Backlight On/Off (2)
	No Function	Time Titel Time, Titel Remain Time, Total Play Time, Total Remain Time, (3)	No Function
	No Function	Programming Mode, (4)	Jump back on the menu again (1) No Function (2)
	Menu up	No Function, (5)	Navigate in the arrow direction (1) No Function (2)
	No Function	CD eject, (6)	Home (1) CD eject (2)
	Input selection up	Skip backward, (7)	Navigate in the arrow direction (1) No Function (2)
	MONO ON/OFF	Repeat On/Off, (8)	Enter No Function (2)
	Input selection down	Skip forward, (9)	Navigate in the arrow direction (1) No Function (2)
	No Function	Pause, (0)	Pause (1),(2)

	 Pre- and Integrated Amplifier	 CD-Player	 Streamer, Mediaplayer
▽	Menu down	No Funktion	Navigate in the arrow direction ⁽¹⁾ No Funktion ⁽²⁾
C	Enter Menu	Turn on numeric keypad	Context Menu ⁽¹⁾ Button Light ⁽²⁾
▷	No Function	Play	Play ^{(1),(2)}
⏮	Decrease volume by 10 units	Rewind	Skip backward ^{(1),(2)}
⏭	Volume increase by 10 units	Fast Forward	Skip forward ^{(1),(2)}
◻	Mute	Stop playing	Stop playing No Funktion ⁽²⁾
◀	Decrease the volume	Decrease the volume at the amplifier	Decrease the volume at the amplifier
▶	Increase the volume	Increase the volume at the amplifier	Increase the volume at the amplifier

(1) Funktion at CHRONOLOG, TRINITY

(2) Funktion at EXXCEED SERVER

Manufacture and Design:

Trigon Elektronik GmbH

Crumbacher Str. 60

D-34277 Fuldabrück-Bergshausen, Germany

Tel.: +49 (0) 561 - 20753880

FAX:+49 (0) 561 – 20753888

e-mail: trigon@trigon-audio.deweb: www.trigon-audio.de

Kassel 12.2018